<u>Airside</u> means the area of the airport that is either contained within the airport perimeter fence, or which requires access through a building located on or adjacent to airport property, or which requires access through a controlled airport access point.

ARTICLE 4 VEHICLES, PEDESTRIANS, ETC.

Section 4-1. General requirements.

No person shall operate a vehicle on the airport except in accordance with the rules prescribed by the airport director and all federal, state and local law.

- (a) Vehicles shall only be operated in the areas airside in a manner that complies with these regulations.
 - 1. No person shall operate airside without an approved driver/vehicle permit for that vehicle operator. in a manner that complies with these regulations
 - 2. A person without an approved driver/vehicle permit shall be permitted to operate a vehicle airside while being monitored by a business or facility that has a vehicle control plan which has been approved by the airport director. The vehicle control plan shall include, but is not limited to, procedures for physical presence, physical barriers, visual examination, and verbal or written instructions.
- (b)(b) Vehicles shall access all airport facilities and businesses from the landside public parking areas for said facility or business.
- (ec) Vehicles shall obtain access to, and depart from, aircraft parking and storage areas via the gate specified in the driver/vehicle permit.
- (dd)—When a gate is out-of-service, vehicles shall access a secondary gate as specified by the out-of-service notification.
- (ee) All vVehicles shall yield right of way to aircraft in motion and emergency vehicles.
- (ff) All-No vehicles shall operate in a careless, negligent or reckless manner or pass no closer than one hundred fifty (10050) feet to the rear of taxiing aircraft.
- (gg)—No vehicles shall operate in a careless, negligent or reckless manner or approach closer than one hundred twenty-five (10025) feet to any aircraft whose engines are running, excluding ground service and emergency vehicles.

(hh)—All vehicles, upon entering or exiting an airport access gate, shall wait for the gate to completely close behind them before proceeding to their destination so as to not allow the entry of an unauthorized vehicle.

Section 4-2. Licensing, registration and insurance.

- (a) No person shall operate a vehicle of any kind on the airport without a current motor vehicle operator's license.
 - 1. No person shall operate any vehicle in the airside area without having first registered the vehicle and its operator with the airport director and obtaining an approved airport driver/vehicle permit which must be displayed at all times in a manner approved by the airport director.
 - 2. A person with an approved driver/vehicle permit may drive a non-permitted vehicle airside as a temporary replacement vehicle for no more than five (5) calendar days with approval by the airport director or designee.
 - 3. A person without an approved driver/vehicle permit may operate a non-permitted vehicle airside as long as an authorized driver/vehicle permit holder is within the vehicle and with approval by the airport director prior to accessing airside.
- (b) All vehicles shall maintain the appropriate type and amount of vehicle liability insurance required by state law.